



PARTS LIST FOR MSP-1

DRWG. NO.	DESCRIPTION	PART NO.
1	PISTON HOUSING ASSEMBLY	1PP-MSP**

PARTS LIST

DRWG. NO.	DESCRIPTION	PART NO.
2	JAW HOUSING	2HA-MSP
3	PISTON SHAFT	3-MSP
5	RETURN SPRING	5-MSP
6	LEVER ASSEMBLY	6TL-MSP
7	SPOOL	7A-MSP
8	SPOOL O'RING (2 required)	16-01-K10***
9	SPOOL O'RING (2 required)	16-003-K10***
10	VALVE BODY	10A-MSP
11	PIVOT SCREW	11-MSP
14	INSERT NUT	14-MSP
15	PISTON CUP	15-MSP
16	LEVER SCREW (2 required)	28-01-K10
18	BUMPER O'RING	18-MSP-K10***
19	ADJUSTMENT SCREW	19-MSP-K5
20	LOCK SCREW	20-MSP-K10
21	BOG SCREW	20-MSP-K10
22	O'RING JAW SPRING	22-MSP-K10

** 1PP-MSP includes trigger assembly, valve assembly, adj. screw and bog screw

*** Only sold as part of O-ring repair kit – BP-MSP-KIT (22-MSP Jaw Spring not included)

102-5	5 FT HOSE 1/8"X1/4" FITTING	102-5
104-	HANGER BRACKET	104