



PARTS LIST FOR SM-100

DRWG. NO.	DESCRIPTION	PART NO.
1	PISTON HOUSING	1-F-SM-100
2	JAW HOUSING	2-SM-100
3	PISTON SHAFT	3-SM-100
15	PISTON O'RING	15A-01
16	RETURN SPRING	16-SM-100
23	PIVOT SCREW	23-01
33	INSERT NUT	33-01